

Soluna Battery Compatibility List

(LV Pack)

(Ver: A.3)

Inverter Brand	Inverter Model	Soluna Bes 2.5K Pack	Soluna EOS- 5K Pack	Soluna 10K Pack LV	Soluna Franz 9.6K Pack LV	Soluna Venus 16K Pack LV	Soluna Jupiter 32K Pack LV	Soluna Bes- 5K Pack	Soluna EVO 5K Pack	Soluna Lyra 5K Pack
Solis	S6-EH1P(3-10)K-L-Plus		√	√	√	√	√	√	√	√
	S6-EH2P(9.6~18)K03-SV-YD-L-US		√	√	√	√	√	√	√	√
	S6-EH3P(8-15)K02-NV-YD-L		√	√	√	√	√	√	√	√
	S6-EH1P(3-6)K-L-EU		√	√	√	√	√	√	√	√
	S5-EH1P(3-6)K-L		√	√	√	√	√	√	√	√
	S6-EH2P(5-8)K02-SV-YD-L		√	√	√	√	√	√	√	√
	S6-EA1P(3.6-6)K-L		√	√	√	√	√	√	√	√
	S5-EA1P3K-L		√	√	√	√	√	√	√	√
	S6-EO1P(4-5)K-48		√	√	√	√	√	√	√	√
	S6-EO1P(4-5)K-48-EU		√	√	√	√	√	√	√	√
GoodWe	EM		√	√	√	√	√	√	√	√
	S-BP		√	√	√	√	√	√	√	√
	ES		√	√	√	√	√	√	√	√
	ET		√	√	√	√	√	√	√	√
	ES G2		√	√	√	√	√	√	√	√
	SBP G2		√	√	√	√	√	√	√	√
	ES Uniq 3-6kw		√	√	√	√	√	√	√	√
	ES Uniq 8-12kw		√	√	√	√	√	√	√	√
MEGAREVO	REVO-48V Series		√	√	√	√	√	√	√	√
VICTRON	MultiPlus-II Series		√	√	√	√	√	√	√	√
SMA	Sunny Island Series		√	√	√	√	√	√	√	√
Afore	AF1-3.6K-SL-1 Series		√	√	√	√	√	√	√	√
	AF3-6K-SL Series		√	√	√	√	√	√	√	√
DEYE	SUN-5-8K-SG01LP1-US		√	√	√	√	√	√	√	√
	SUN-3.6-8K-SG01LP1-EU		√	√	√	√	√	√	√	√
	SUN-12-16K-SG01LP1-EU		√	√	√	√	√	√	√	√
	SUN-3.6-6K-SG03LP1-EU		√	√	√	√	√	√	√	√
	SUN-3-6K-SG04LP1-EU		√	√	√	√	√	√	√	√
	SUN-5-12K-SG04LP3-EU		√	√	√	√	√	√	√	√
	SUN-3.6-8K-SG05LP1-EU		√	√	√	√	√	√	√	√
APsystems	ELS 5K		√	√	√	√	√	√	√	√
	ELS 11K		√	√	√	√	√	√	√	√
Phocos	PSW-H-5KW-230/48V		√	√	√	√	√	√	√	√
Voltronic Power	Rebel EO Max		√	√	√	√	√	√	√	√
	VM IV-4000 TWIN-PV 5600	√								
Hoymiles	HYS-LV-EUG1		√	√	√	√	√	√	√	√
	HYS-LV-USG1		√	√	√	√	√	√	√	√
	HIT-20L-G3		√	√	√	√	√	√	√	√
AiSWEI	ASW H-S2 Series		√	√	√	√	√	√	√	√
MUST	PV18-5248 PRO		√	√	√	√	√	√	√	√
SolaX	X1-Hybrid-LV Series		√	√	√	√	√	√	√	√
SRNE	ASF4880U180-H		√	√	√	√	√	√	√	√
	ASF48100U200-H		√	√	√	√	√	√	√	√
LUXPower	ECO Hybrid SNA (3-6K)WPV		√	√	√	√	√	√	√	√
	LXP-US 8-12K		√	√	√	√	√	√	√	√
Growatt	SPH 10000TL-HU-US		√	√	√	√	√	√	√	√
	SPH 8-10kTL-HU-US(B)		√	√	√	√	√	√	√	√
	SPE 6-12K US		√	√	√	√	√	√	√	√
	SPM 8-10KTL-HU		√	√	√	√	√	√	√	√
	SPM 3-6KTL-HU		√	√	√	√	√	√	√	√
	SPH 10000TL-HU		√	√	√	√	√	√	√	√
	SPE 6-12KTL-ES		√	√	√	√	√	√	√	√
	WIT 4-15K-HU		√	√	√	√	√	√	√	√
	SPH 3-6KTL BL-UP		√	√	√	√	√	√	√	√
	SPF 6000ES Plus		√	√	√	√	√	√	√	√
	SPF 3-5K ES		√	√	√	√	√	√	√	√
	SPF 3.5-5K ES Lite		√	√	√	√	√	√	√	√
	SPF 2-5KTL HVM		√	√	√	√	√	√	√	√
	SPF 3000TL LVM		√	√	√	√	√	√	√	√
	SPF 3.5-5KTL HVM-Pro		√	√	√	√	√	√	√	√
	SPF 3-6KTHVM-G2		√	√	√	√	√	√	√	√
	SPF 4-12KT HVM		√	√	√	√	√	√	√	√
	SPF 6000T DVM-G2		√	√	√	√	√	√	√	√
	SPF 4-12KT DVM		√	√	√	√	√	√	√	√
	SPF 4-18KTDVM-MPV		√	√	√	√	√	√	√	√
SAJ	H2-5-12K-LS2		√	√	√	√	√	√	√	√
	H2-11.4K-LS4-US		√	√	√	√	√	√	√	√
HYPONTECH	HES 3-6K		√	√	√	√	√	√	√	√
Swatten	SiH-6kW-SL		√	√	√	√	√	√	√	√
Sinexcel	Isuna 01.5K-06K		√	√	√	√	√	√	√	√
SOSEN	SSE-HL6K-P1EU		√	√	√	√	√	√	√	√
	SSE-HL3~8K-P1EU		√	√	√	√	√	√	√	√
	SSE-HL8~15K-P2SA		√	√	√	√	√	√	√	√
	SSE-HL8~15K-P2US		√	√	√	√	√	√	√	√
	SSE-HL8~24K-P3EU-S		√	√	√	√	√	√	√	√
	SSE-HL10~16K-P1EU-S		√	√	√	√	√	√	√	√
Sola-ark	Sol-Ark 8K-2P		√	√	√	√	√	√	√	√
	Sol-Ark 12K-2P		√	√	√	√	√	√	√	√
	Sol-Ark 15K-2P		√	√	√	√	√	√	√	√
	Sol-Ark 18K-2P		√	√	√	√	√	√	√	√

Remark:

1. Soluna battery packs are not allowed to work with inverters not listed, or we are not responsible for any technical support.

2. The list is constantly being updated, please confirm with Soluna for the latest version.